

CAMTREE HUNT

Mod Cage For Blackmagic Pocket
Cinema Camera

(CH-MODC-BMPC)

INSTRUCTION MANUAL



All rights reserved.


No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

INTRODUCTION

In order to get the best out of your Blackmagic Pocket Cinema Camera, Camtree Hunt proudly unveils its peculiar Mod cage for BMPCC cameras to give your every shot a more refined & professional feel. The robust video cage not only covers your camera for multiple mounting choices but also keeps it protected. The sturdy top handle allows front and back positioning as per your shooting needs, locking clamp prevents accidental cable disconnects and shoe mount with 1/4"-20 threads fully optimizes your camera cage.

IN THE BOX

Please inspect the contents of your shipped package to ensure you have received all that is pictured and listed below.



ASSEMBLING Mod Cage For BMPC

- Attach 15mm rod adapter to mod cage with help of provided knob and slide the cage to sliding base plate, tighten properly as shown below.



- Now insert camera into the cage and tighten the screw with help of screw driver.



- Attach the lens (not included) to camera.



- Now attach the top handle on cage top and tighten the knob to secure.



- Attach the set up to tripod plate and tighten with screw driver.



- Then mount the set up on to tripod and secure with provided knob.



- Insert rails into the rod adapter and tighten the provided knob to ensure slip free connection.



NOTE: Loosen front cage knobs with help of allen key and insert A-Box wire to it.



- Then clip A-Box wire to rails with help of wire organizer clamp.



**YOUR CAMTREE HUNT MOD CAGE FOR BLACKMAGIC POCKET CINEMA CAMERA
ALL DRESSED UP AND READY TO GO**



(SHOWN WITH OPTIONAL ACCESSORIES)

WARRANTY

We offer a one year warranty for our products from the date of purchase.

We will repair or replace your product, free of charge, in the event of a defect in materials or craftsmanship obtained during normal use or handling based on the user manual. Please note that we will not cover any shipping costs for returning the product to us. If any VAT or import duties are applied to the return, we will also charge these costs to the customer.

The warranty does not include, by the way of example, damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product , or service by anyone other than our company.

We are not liable for incidental or consequential damages resulting from the use of the unit or occurring due to any breach of this warranty.

Replacement parts of the product will be provided at nominal cost (covering the cost price of the replacement parts only) to the customers after the Warranty Period has expired. We will cover the complete cost of sending replacement parts within the warranty period. After that, nominal cost of the product & Actual shipping cost will be charged.

Do not send the unit to us without first getting a response and getting the approval to send back the item.

In case of any kind of dissatisfaction, we urge you to Contact us immediately and we shall do our best to help you out.

For any other assistance you can reach us via email.